
# Self Powered RF+Bluetooth DIM Remote Controller

70200001

Bluetooth° (€ F© BROHS COMPLIANT


Important: Read All Instructions Prior to Installation

## **Function introduction**




Front side

#### With Plastic Frame



#### Back side

#### With Glass Frame



The remote control can be fixed on the wall with 3M glue or screw.

#### **Product Data**


Protocol	RF+Bluetooth
Power Supply	Self powered by built-in nano generator
Transmission Frequency	2.4GHz
Transmission Range (free field)	30m
Protection Type	IP20
Dimming Range	0.1%-100%
Dimensions	80.5x80.5x14.7mm / 86x86x14mm

- DIM wall remote based on RF+Bluetooth Mesh
- Self-powered wall remote, no battery replacement & re-installation costs
- · No wires, no batteries, no limits
- Ultra long lifetime, more than 1 million times pushing
- Easy & quick pairing to the RF+Bluetooth receivers by simply pushing the buttons
- Enables to control 2 zones of receivers
- Mesh network for further control distance, receivers can transmit signal to each other
- 2.4 GHz global operation
- The controlled receiver status can be quickly synchronized to the smart APP
- Transmission range between every two neighbor devices up to 30m
- Each receiver can be paired to max. 8 remote controls
- Enables to control universal DIM RF+Bluetooth devices
- Standard size, compatible with existing EU size frame

# Safety & Warnings

• DO NOT expose the device to moisture.

# Pair with RF+Bluetooth receiver



**Step 1:**Do wiring the RF+Bluetooth receiver according to wiring diagram(please refer to the instruction of RF receiver that you would like to pair with)




Step 2:Click the "Prog." or "Reset" button on the receiver or re-power on the receiver three times continuously to set it into pairing status

Step 3:Click | or O button of either of the two zones on the remote, e.g. button O of zone 2, LED lights connected with the receiver flicker once means the receiver is paired to the selected zone successfully.

Note: one receiver can be paired with max 8 remote controls.

## Installation



The key part of this controller is a universal, extremely rotary standard switch element that can be integrated in numerous frames by different manufactures as below list:

BEKER	S1, B1, B3, B7 glass
GIRA	Standard55, E2, Event, Esprit
JUNG	A500, Aplus
MERTEN	M-smart, M-Arc, M-Plan